



- The light sensor measures the daylight entering the room
- Installation: surface-mounted on ceiling
- For connecting to the local control units

Sensor (light) surface-mount