



- For harsh and hazardous areas
- Flexible
- Engineered to order

Aluminium distribution boxes have proven to be an excellent solution for encapsulating and shielding components and modules in electronic and pneumatic engineering. Bottom and lid of the distribution boxes come with earthing screws for the connecting of the protective conductor. Mounting threads in the bottom section, fixing holes outside of the sealed space. The same high quality explosion-proofed enclosures are used in hazardous areas by inflammable dust (Zone 21 and 22). By means of the heating calculation according to the supplement to the test certificate and a separate IP-protection test, the basic requirements of the "protection through enclosure" type of protection are met.

IP distribution box	grey	07-5172-.../....
Ex e distribution box	grey	07-5101-.../....
Ex i distribution box	grey	07-5102-.../....

Explosion protection

Marking ATEX	⊕ II 2G Ex eb ia/ib IIA, IIB, IIC T6 oder T5 Gb ⊕ II 2D Ex tb IIIC T80 °C, T95 °C Db IP 66
Certification for Zone 1 and Zone 2	PTB 11 ATEX 1016X
Marking IECEx	Ex eb ia/ib IIA, IIB, IIC T6 oder T5 Gb Ex tb IIIC T80 °C, T95 °C Db IP 66
Certification for Zone 21 and Zone 22	PTB 11.0033X
Other approvals and certificates, see www.bartec.de	
Ambient temperature (specific designs available on request)	-20 °C to +40 °C for T6 -55 °C to +55 °C for T5 optionally up to +65 °C (T5)

Technical data

Material	aluminium, die or shell casting, AlSi 12, Mg < 6 thread -%
Colour/coating	RAL 7001, silver grey, optionally unpainted special varnish and seawater-resistant varnish on request
Lid screws (other models on request)	stainless steel, captive, cross-head (+ -)
Standard seals	CR -28 °C to +95 °C optional silicone -55 °C to +100 °C
Mechanical resistance	impact energy 7 Nm (EN/IEC 60079-0)
Protection class	IP 66 EN/IEC 60529
Rated voltage	max. 1 100 V
Rated maximum current	please refer to Operating Instructions Document, page 4–10 https://www.bartec.de/ProdCatalogue/Assets/Manuals/Ing_0/EN_Distribution_Box_07_5101(2).pdf

Installation instructions

The installer must make sure that the enclosure used is suitable for the corresponding field of application. This means that the marking must correspond to the classification of the Ex area. Also must the temperature class of the distribution box meet the respective requirements.

Aluminium distribution boxes for Zone 1/21 and Zone 2/22

The table on this page applies to the following aluminium distribution boxes:

IIP distribution box 07-5172-.../.... Ex e distribution box 07-5101-.../.... Ex i distribution box 07-5102-.../....

Rail-mounted terminals/maximum number

Aluminium enclosure Article no.	Mini-terminal 07-7902-....		AKZ4 03-7112-0008		WDU 2,5 03-7111-0012		WDU 2,5 bl 03-7111-0012		WDU 4 03-7112-0015	
	mounting- rail	Terminals per rail	mounting- rail	Terminals per rail	mounting- rail	Terminals per rail	mounting- rail	Terminals per rail	mounting- rail	Terminals per rail
07- [] [] [] [] -0580/6436	-	3	-	-	-	-	-	-	-	-
07- [] [] [] [] -0980/6436	-	7	-	-	-	-	-	-	-	-
07- [] [] [] [] -1500/6436	-	11	-	-	-	-	-	-	-	-
07- [] [] [] [] -0750/8057	1	5	1	7	-	-	-	-	-	-
07- [] [] [] [] -1250/8057	1	10	1	16	-	-	-	-	-	-
07- [] [] [] [] -1750/8057	1	14	1	22	-	-	-	-	-	-
07- [] [] [] [] -1221/2080	2	8	1	14	1	16	1	16	1	14
07- [] [] [] [] -1221/2090	2	8	1	14	1	16	1	16	1	14
07- [] [] [] [] -2201/2080	2	17	1	30	1	35	1	35	1	30
07- [] [] [] [] -2201/2090	2	17	1	30	1	35	1	35	1	30
07- [] [] [] [] -3601/2080	-	-	-	-	1	60	1	60	1	49
07- [] [] [] [] -1601/6090	-	-	2	18	1	24	1	23	1	20
07- [] [] [] [] -2601/6090	-	-	2	34	1	43	1	42	1	34
07- [] [] [] [] -3601/6090	-	-	-	-	1	60	1	62	1	50
07- [] [] [] [] -5601/6090	-	-	-	-	1	98	1	102	1	85
07- [] [] [] [] -2002/1011	-	-	3	25	2	30	2	30	2	25
07- [] [] [] [] -2802/1011	-	-	-	-	2	44	2	44	2	38
07- [] [] [] [] -3302/1011	-	-	-	-	2	56	2	53	2	46
07- [] [] [] [] -4002/1011	-	-	-	-	2	70	2	68	2	58
07- [] [] [] [] -6002/1011	-	-	-	-	2	108	2	109	1	90
07- [] [] [] [] -4003/1011	-	-	-	-	3	70	3	68	2	58
07- [] [] [] [] -6003/1011	-	-	-	-	2	110	2	110	2	91

Technical data subject to change without notice.



The table on this page applies to the following aluminium distribution boxes:
 IIP distribution box 07-5172-.../.... Ex e distribution box 07-5101-.../.... Ex i distribution box 07-5102-.../....

Ordering information


Aluminium enclosure Article no.	External dimensions in mm			Earth bars/Mantle terminal				Mounting panel
	Length	Width	Height	Type	Order no.	Type	Order no.	Order no.
07-□□□□-0580/6436	58	64	36	SB 2	05-0012-0002	-	-	05-2105-0094
07-□□□□-0980/6436	98	64	36	SB 2	05-0012-0002	-	-	05-2105-0095
07-□□□□-1500/6436	150	64	36	SB 2	05-0012-0002	-	-	05-2105-0096
07-□□□□-0750/8057	75	80	57	SB 2	05-0012-0002	-	-	05-2105-0097
07-□□□□-1250/8057	125	80	57	SB 2	05-0012-0002	-	-	05-0105-0098
07-□□□□-1750/8057	175	80	57	SB 2	05-0012-0002	LS 4	-	05-0105-0099
07-□□□□-1221/2080	122	120	80	QS 3	05-0012-0002	LS 4	05-0012-0100	05-0105-0100
07-□□□□-1221/2090	122	120	90	QS 3	05-0012-0002	LS 9	05-0012-0100	05-0105-0100
07-□□□□-2201/2080	220	120	80	QS 3	05-0012-0091	LS 5	05-0012-0101	05-0105-0101
07-□□□□-2201/2090	220	120	90	QS 3	05-0012-0091	LS 5	05-0012-0101	05-0105-0101
07-□□□□-3601/2080	360	120	80	QS 3	05-0012-0091	LS 11	05-0012-0103	05-0105-0102
07-□□□□-1601/6090	160	160	90	QS 5	05-0012-0092	LS 16	05-0012-0010	05-0105-0103
07-□□□□-2601/6090	260	160	90	QS 5	05-0012-0092	LS 11	05-0012-0012	05-0105-0106
07-□□□□-3601/6090	360	160	90	QS 5	05-0012-0092	LS 11	05-0012-0014	05-0105-0105
07-□□□□-5601/6090	560	160	90	QS 5	05-0012-0092	LS 18	05-0012-0107	05-0105-0107
07-□□□□-2002/1011 07-□□□□-3302/3018	200	230	110	QS 7	05-0012-0098	LS 18	05-0012-0108	05-0105-0108
07-□□□□-2802/1011	280	230	110	QS 7	05-0012-0098	LS 18	05-0012-0109	05-0105-0109
07-□□□□-3302/1011 07-□□□□-3302/3018	330	230	110	QS 7	05-0012-0098	LS 18	05-0012-0110	05-0105-0110
07-□□□□-4002/1011	400	230	110	QS 7	05-0012-0098	LS 28	05-0012-0016	05-0105-0111
07-□□□□-6002/1011	600	230	110	QS 7	05-0012-0098	LS 28	05-0012-0111	05-0105-0112
07-□□□□-4003/1011 07-□□□□-4002/1018	400	310	110	QS 13	05-0012-0099	LS 28	05-0012-0016	05-0105-0115
07-□□□□-6003/1011 07-□□□□-6003/1018	600	310	110	QS 13	05-0012-0099	LS 28	05-0012-0111	05-0105-0116

QS = diagonal strip/horizontal alignment, e.g.: LS 4 = 4 clamping points for 8 connections
 LS = horizontal strip/vertical strip, e.g.: QS 3 = 3 clamping points for 6.

Technical data subject to change without notice.



The table on this page applies to the following aluminium distribution boxes:
 IIP distribution box 07-5172-.../.... Ex e distribution box 07-5101-.../.... Ex i distribution box 07-5102-.../....



Aluminum distribution box with lid Cable glands/maximum number

Aluminium enclosure Article no.	Side	M12 x 1.5	M16x 1.5	M16 x 1.5 extended	M20 x 1.5	M20 x 1.5 extended	M25 x 1.5	M32 x 1.5	M40 x 1.5	M50 x 1.5	M63 x 1.5
07- [] [] [] [] -0580/6436	A/B C/D	1 -	1 -	1 -	- -	- -	- -	- -	- -	- -	- -
07- [] [] [] [] -0980/6436	A/B C/D	3 1	3 1	3 1	- -	- -	- -	- -	- -	- -	- -
07- [] [] [] [] -1500/6436	A/B C/D	6 1	5 1	4 1	- -	- -	- -	- -	- -	- -	- -
07- [] [] [] [] -0750/8057	A/B C/D	5 2	3 2	2 2	2 1	1 -	1 -	- -	- -	- -	- -
07- [] [] [] [] -1250/8057	A/B C/D	9 2	6 2	4 2	3 1	3 1	2 -	- -	- -	- -	- -
07- [] [] [] [] -1750/8057	A/B C/D	14 2	9 2	6 2	5 1	4 1	3 -	- -	- -	- -	- -
07- [] [] [] [] -1221/2080	A/B C/D	12 4	10 4	6 3	6 2	5 2	3 1	2 1	1 -	1 -	1 -
07- [] [] [] [] -1221/2090	A/B C/D	12 4	9 4	6 2	5 2	4 2	2 -	1 -	1 -	1 -	1 -
07- [] [] [] [] -2201/2080	A/B C/D	27 4	17 4	12 3	11 2	10 2	5 1	3 1	3 -	2 -	2 -
07- [] [] [] [] -2201/2090	A/B C/D	27 4	17 4	12 2	11 2	10 2	5 -	3 -	3 -	2 -	1 -
07- [] [] [] [] -3601/2080	A/B C/D	48 4	30 4	22 4	21 2	18 2	9 1	6 1	5 -	- -	- -
07- [] [] [] [] -1601/6090	A/B C/D	18 8	14 8	8 5	8 4	6 4	4 2	2 -	1 -	1 -	1 -
07- [] [] [] [] -2601/6090	A/B C/D	33 8	26 8	17 5	14 4	12 4	7 2	4 -	3 -	3 -	2 -
07- [] [] [] [] -3601/6090	A/B C/D	48 8	38 8	24 5	20 4	18 4	10 2	6 -	5 -	4 -	3 -
07- [] [] [] [] -5601/6090	A/B C/D	84 8	60 8	42 5	34 4	28 4	20 2	10 -	8 -	6 -	4 -
07- [] [] [] [] -2002/1011	A/B C/D	38 20	24 15	16 10	15 10	12 6	8 4	5 3	3 2	2 2	2 1
07- [] [] [] [] -2002/3018	A/B C/D	64 56	36 42	25 25	25 25	16 16	16 16	9 9	4 4	4 4	4 4
07- [] [] [] [] -2802/1011	A/B C/D	58 20	30 15	25 10	23 10	20 6	11 4	8 3	4 2	3 2	2 -
07- [] [] [] [] -3302/1011	A/B C/D	70 20	46 15	30 10	28 10	24 6	14 4	10 3	5 2	4 2	2 1
07- [] [] [] [] -3302/3018	A/B C/D	120 56	72 36	50 25	45 25	32 16	28 12	18 9	8 4	8 4	6 4
07- [] [] [] [] -4002/1011	A/B C/D	58 20	56 15	38 10	35 10	30 6	17 4	12 3	6 2	4 2	3 1
07- [] [] [] [] -6002/1011	A/B C/D	126 25	84 15	56 10	52 10	46 6	24 4	18 3	8 2	6 2	4 1
07- [] [] [] [] -4003/1011	A/B C/D	85 30	56 25	38 20	35 18	30 10	17 5	12 4	6 2	4 2	3 1
07- [] [] [] [] -4003/1018	A/B C/D	144 84	90 60	65 45	60 40	44 28	36 24	21 15	12 8	10 6	8 6
07- [] [] [] [] -6003/1011	A/B C/D	126 30	84 25	56 20	52 18	46 10	24 5	18 4	8 2	6 2	4 1
07- [] [] [] [] -6003/1018	A/B C/D	208 84	132 60	90 45	90 40	80 28	56 18	30 15	16 8	16 6	12 6

Each enclosure side wall has only a limited number of gland entries to ensure the mechanical stability of the enclosure.

Technical data subject to change without notice.